

## I. Safety Information

Do not operate the unit if the casing or the test Leads are or look damaged.

Check the main function dial to ensure it is set at the correct position before each measurement.

Do not perform resistance and continuity test on a live "powered" system.

Do not apply voltage between the test terminals and test terminal to ground that exceed the maximum limit referred to in this manual.

Exercise extreme caution when measuring live systems with voltage greater than 60V DC or 30V AC.

Keep fingers behind the protection ring when measuring with test leads.

Replace batteries when the  symbol appears to avoid incorrect data.

Environmental Conditions:




Altitude up to 2000 meters.


Operating temperature: 0°C ~ 40°C, <80% RH, non-condensing

Storage temperature: -10°C ~ 60°C, <70% RH, battery removed

Pollution Degree: 2

Explanation of Symbols:

-  Attention refer to operation Instructions.
-  Dangerous voltage may be present at terminals.
-  This instrument has double insulation.

Approvals:  EN61010 600V CAT II 300V CAT III

## II. Specification

General Specification:

**Digital Display:**

4 digits LCD display with maximum reading 9999

**Over Load:**

When the signal input exceeds the maximum limit "OL" will be display.


**Sample Rate:**

2 times/sec

**Peak Hold Sample Rate:**

10ms at DCV, DCA

**Low Power Indication:**

When the battery is below the proper operation range,  symbol will appear on the LCD display.

**Auto Power Off:**

The meter will power it self OFF after 30 minutes of inactivity.

**Electromagnetic Compatibility:**

Vac and Aac only: RF field = 3V/m

Total accuracy = specified accuracy + 5.0% of range

**Power Source:** UM-4 or AAA 1.5V battery x 2.

**Battery Life:** 45 hr approx. (alkaline battery)

**Clamp opening size:** 12.5mm(1/2 inch)

**Dimension (L x W x H) :**

202x70x34mm, 7.95x2.76x1.33 inch

**Weight:** 180g( include battery)

**Accessory:**

Instruction Manual, Carrying Case, Test lead, Battery 1.5Vx2

## Electrical Specification:

( I ) The accuracy specification is defined as  $\pm( \dots\% \text{reading} + \dots \text{count} )$  At  $23 \pm 5^{\circ}\text{C}$ ,  $\leq 80 \% \text{RH}$

**ACA (Aurange)**

Range	Resolution	Accuracy ( 50Hz~500Hz)	Overload Protection
10A	1mA	2%+10	150Arms
80A	10mA		
80~100A	10mA	3.5%+10	

Accuracies are specified from 5% to 100% of range

**DCA (Aurange)**

Range	Resolution	Accuracy	Overload Protection
10A	1mA	2.5%+10	150Arms
80A	10mA		
80~100A	10mA	4.5%+10	

Accuracies are specified from 5% to 100% of range

**ACV**


Range	Resolution	Accuracy (50Hz~500Hz)	Overload Protection
600V	0.1V	1.5%+5	660Vrms


**DCV**

Range	Resolution	Accuracy	Overload Protection
600V	0.1V	1%+2	660Vrms

**Ohm (  $\Omega$  )**

Range	Resolution	Accuracy	MAX Test Voltage	Overload Protection
10K $\Omega$	1 $\Omega$	1%+3	3VDC	600Vrms

**Continuity (  )**

Range	Active Region	MAX Test Voltage	Overload Protection
	<100 Ohm	3VDC	600Vrms

( II ) Analog output: ( for ACA & DCA range)

10 mV/Amp (20KHz at  $\pm 3\text{dB}$ )

Accuracy:  $\pm(4.5\% \text{ reading} + 0.5\text{mV})$

Output impedance: approx 3K $\Omega$

Overload protection: 600 Vrms



- |                          |                           |
|--------------------------|---------------------------|
| ① Current Sensing Clamp  | ⑥ Positive input terminal |
| ② Safety protection ring | ⑦ Function select dial    |
| ③ Clamp opening handle   | ⑧ Peak / Data hold button |
| ④ LCD display            | ⑨ Zero button             |
| ⑤ COM input terminal     |                           |

## Button Instruction:

### ▪ Zero Button

Press Zero button to enter the Zero mode, “ $\Delta$ ” Annunciate will appear and Zero the display. The reading is stored as reference value for subsequent measurement.  
Press the Zero button again, to exit the zero mode.

### ▪ Data Hold & Peak Hold Button

To activate the Data Hold feature, press and hold the “**Hold**” button.

To de-activate the Data Hold feature, press and hold the “**Hold**” button again.


To activate the Peak Hold feature, press and hold the “**Peak**” button until the symbol displays.

To deactivate the Peak feature, press and hold the “**Peak**” button for 2 seconds.

The meter will return to normal mode operation.

**Note:** This meter is built with peak hold function at ACA, DCA, ACV, DCV ranges.

### ▪ Disable Auto power off

Press and hold “**ZERO**” button and then the power on the meter, the  symbol will disappear.

## IV. Measuring Instruction:

### 4.1 ACA measurement:

Switch the function selector to A~ range.

Open the clamp by pressing the jaw-opening handle and insert the cable to be measured into the jaw.



Close the clamp and get the reading from the LCD panel.

#### **Note:**

Before this measurement, disconnect any test lead with the meter for safety.

In some cases where reading is difficult, press the HOLD button and read the result later.

4 CORRECT



7 INCORRECT

## 4.2 DCA measurement:

Switch the function selector to A  $\overline{\text{---}}$  range.

Press ZERO button to enter the zero reading.


Open the clamp by pressing the jaw-opening handle and insert the cable to be measured into the jaw.

Close the clamp and get the reading from the LCD panel.

### **Note:**

Before this measurement, disconnect any test lead from the meter for safety.

In some cases where reading is difficult, press the HOLD button and read the result later.



### 4.3 ACV Measurement:

#### **⚠ WARNING!**


Maximum Input Voltage is 600V AC/DC. Do not attempt to Take any voltage measurement that may exceed this maximum to avoid Electrical shock hazard and/or damage to this instrument.

Switch the function selector to  $V \sim$  range.

Connect red test lead to “+” terminal and black one to the “COM” terminal.

Measure the voltage by touching the test lead tips to the test circuit where the value of voltage is needed.

Read the result from the LCD panel.






#### 4.4 DCV measurement:

Switch the function selector to **V**  $\text{---}$  range.

Connect red test lead to “+” terminal and black one to the “COM” terminal.

Measure the voltage by touching the test lead tips to the test circuit where the value of voltage is needed.

Read the result from the LCD panel.



#### 4.5 Resistance measurement:

Switch the function selector to  $\Omega$  range.


Connect red test lead to “+” terminal and black one to the “COM” terminal.

Connect tip of the test leads to the points where the value of the resistance is needed.


Read the Ohm value from the LCD panel.

**Note:**

When measuring resistance value from a circuit, make sure the power is cut off and all capacitors are discharged.




#### 4.6 Continuity Test:

Switch the function selector to  range.

Connect red test lead to “+” terminal and black one to the “COM” terminal.

Connect tip of the test leads to the points where continuity is to be tested.

If the resistance is under  $100\Omega$ , the beeper will sound continuously.



#### 4.7 Analog Signal Output:

Switch the function selector to A  $\overline{\text{---}}$  or A $\sim$  range.

Connect red test lead to “+” terminal and black one to the “COM” terminal.


Connect tip of the test leads to the meter or oscilloscope input terminal.

Open the clamp by pressing the jaw-opening handle and insert the cable to be measured into the jaw.


Close the clamp and get the analog voltage signal from the meter.

**Note:**

If measuring DC via clamp, signal output will be DC voltage. If measuring AC via clamp, signal output will be AC voltage.



## V. Battery Changing:

1. When the battery voltage drops below proper operation range the  symbol will appear on the LCD display and the battery will need to be changed.
2. Before changing the battery, switch the function selector to "OFF" and disconnect test leads.  
Open the back cover using a screw driver. Replace the old batteries with two UM-4 or AAA size batteries.
3. Close the back cover and fasten the screw.

## VI. Maintenance:

### CAUTION

To avoid contamination or static damage, do not touch the circuit board without proper static protection.

### REMARK

- \* Remove the batteries, if the meter is not used for extended periods of time. Do not store the meter in a high temperature/humidity environment.
- \* When measuring current, keep the cable at the center of the clamp to get more accurate readings.

### CLEANING

Periodically wipe the case with a dry cloth and without detergent. Do not use abrasives or solvents on this instrument.